

**Place the following paragraph at the bottom of Page 2-3.**

If the instrument is a butt weld assembly, be sure to do the following: Remove the circuit board, properly ground the flow element before welding, GTAW welding is highly recommended.